

# FIRMWARE UPDATE

## Installation:

1. Download the latest Firmware for the FLOW machines at <https://craftbot.com/firmware>
2. Copy **CRAFT\_UPDATE.ZIP** to a FAT32 formatted usb drive
3. Put the pendrive in to the **HMI port**
4. Wait for the pendrive icon appear on the top right corner of the screen
5. Go to **SETTINGS** and then the **UPGRADE** menu
6. Press the **RESCAN** button until the **UPDATE FROM PENDRIVE** appears
7. Tap the **UPDATE FROM PENDRIVE** to start the update process
8. Update is automatic, when it is ready, click on the **UPDATE FINISHED OK** button

## Troubleshooting:

If the FW update run into error, please do the following:

1. **Turn off** the printer
2. With a piece of filament push and **hold the reset button** (a little hole under the ethernet port)
3. **Turn on** the printer
4. **Release the button**
5. **Install the FW** as above